

FAQ – Beach Rocker

➤ Use

○ **Which features does the Beach Rocker offer me?**

The Beach Rocker is a portable rocking chair that you can easily take anywhere. Use the Beach Rocker on the beach, in the back yard, on your rooftop terrace or take it to the park. The chair has bent gliders, giving it a soothing swing. Foldable and lightweight, you easily take it with you to your favorite spot!

○ **What does the Beach Rocker not withstand?**

Too much exposure of the Beach Rocker to bright sunlight and bad weather conditions, such as storm and rain, can cause discoloration.

➤ Safety

○ **What safety hazards does the Beach Rocker pose?**

Always check if the rocking chair is folded out correctly. The chair is folded out correctly if the crossbar fits well in the notch. Beware of entrapment of fingers or hands when folding or unfolding the rocking chair. Incorrect or rough use (e.g. hard falling or jumping in the chair) may cause the textile to tear. When used normally the Beach Rocker poses little risk.

○ **Are there hazards for small children or other target groups?**

There are no additional risks for small children and other target groups other than mentioned above.

➤ Maintenance

○ **What do I need to pay attention to when maintaining the Beach Rocker?**

The seat of the Beach Rocker consists of cotton with a dirt-repellent coating, the frame is made of varnished beech wood. Stains in the textile can be removed with warm water. When using cleaning products we advise to always test the product on a small piece of the chair beforehand, to prevent damage.

○ **How important is maintenance to the Beach Rocker?**

It's important to make sure that the Beach Rocker is not exposed to bad weather conditions for too long. In addition, it's advisable to keep the textile clean; remove food residue and stains with warm water.

○ **How long will the Beach Rocker last?**

The life span of the Beach Rocker strongly depends on the use. When used carefully (little to no exposure to bright sunlight and bad weather conditions) and by storing the (1) indoors after use, the (1) will last a very long time.

➤ Weather conditions

○ **How can I protect the Beach Rocker from bad weather conditions?**

Fold the Beach Rocker and store it in a dry, covered space.

➤ Material

○ **What materials does the Beach Rocker consist of?**

Cotton with a dirt-repellent coating and varnished beech wood.

○ **How much does the (1) weigh?**

5kg.

○ **Is the Beach Rocker easy to transport?**

The rocking chair is light and foldable, making it easy to transport.

➤ Packaging

○ **How will the Beach Rocker be packaged?**

The Beach Rocker is packaged flat (folded) in a cardboard box. This is done as compactly as possible, to limit the use of cardboard.

○ **What packaging materials are used?**

A cardboard box.